

Kaito

KA11

PLL FM STEREO/AM/SW SYNTHESIZED WORLD
RECEIVER WITH 1,000 MEMORIES

Kaito

KA11

PLL FM STEREO/AM/SW SYNTHESIZED WORLD
RECEIVER WITH 1,000 MEMORIES

OPERATION MANUAL



ACCESSORIES

Please check before buying:

- KA11
- External Adaptor
- Stereo Earphones
- External Antenna
- Carrying Strip
- Operation Manual
- Warranty Card


KEY FEATURES

- FM MONO STEREO/AM/SW.
- MW(AM) 520 - 1710 KHz.
- SW: 5.80 - 18.10 MHz.
- FIVE TUNING MODES: MANUAL TUNING/AUTO TUNING/MEMORY SCAN/DIRECT FREQUENCY INPUT/ATS PRESET.
- 1000 PRESET STATIONS AND MEMORY PERMANENTLY STORED(EXCEPT CLOCK).
- BATTERY CHARGER.
- ORANGE BACKLIGHT DISPLAY.
- 10 LEVEL SIGNAL STRENGTH INDICATOR.
- LOCAL/DX SENSITIVITY SELECTABLE.
- FM MONO/STEREO SELECTABLE.
- THREE GROUPS TURN ON/OFF.
- ALARM FUNCTION(EFFECTIVE IN TURN ON/OFF MODE).
- 1~99 MINUTES SLEEP OFF TIME SETTING.
- CLOCK FUNCTION, TEMPERATURE FUNCTION AND HOLD FUNCTION.
- SW METER BAND INDICATOR AND CONVERSION.

KEY FEATURES

- ERROR INDICATION.
- BATTERY LEVEL INDICATOR, AUTO POWER OFF WHEN BATTERIES GET LOW.
- EXTERNAL ANTENNA.
- USE 2 AA BATTERIES, NOT INCLUDED.
- DIMENSIONS: 110x71x23mm.


LOCATION OF CONTROLS



➊ TelescopicAntenna	➑ FM Band/FM Stereo, Mono, Treble/Time 1	➏ Turn Page/Charge
➋ Place for Carrying Strip	➐ MW Band/Time 2	➍ Power
➌ External Antenna	➑ SW Band/Time 3/Meter Band Conversion	➎ Delete/Backlight Switch
➍ Local/DX	➒ Enter/Confirm	➏ Earphone Jack
➎ Speaker	➓ +/- Key	➑ LCD
➏ Battery Compartment	➑ Setup	➒ Volume Knob
➐ 0~9	➓ External Power Jack	
➑ Exit/Look Up Time	➓ Store/Hold	

LOCATION OF CONTROLS

LCD IDENTIFICATION



Error
 Frequency/
 Hours, Minutes
 External Power
 Weak Power/
 Charge
 Signal Strength/
 Charge Course
 Station No./Page No./
 Temperature/Charge
 Time Count Down
 Sleep Power Off Time
 /Meter Band/Seconds
 Sleep Power off Indicator
 Stereo/Mono Indicator